

# ANTIQUE TRACTOR SHOW & DEMO PULL

Thanksgiving Monday

Enter Gate #3

**Show Chairperson:** Evan Calder 705-639-5240

**Show Committee:** Andy Calder  
Kyle Keating

**Admission:** Tractor & Driver are admitted FREE!  
All others are \$15.00 each

Weight in starts at **10am**

Demo Pull starts **12 Noon Sharp**

All participants must sign a waiver form holding the Norwood Agricultural Society **not liable** for any damage or injury caused by the Tractor Exhibitor. All participants must carry Public Liability Insurance and must be able to provide proof of same upon request of NAS. Norwood Fair Antique Tractor Show & Demo Pull operates under “**Orono Heritage Tractor Club Antique Tractor Pulling Demonstration Rules (2020)**” The following pulling demonstration rules have been developed in the interest of preserving and displaying antique tractors. It is anticipated that all persons participating in pulling demonstration events will accept these rules for this purpose and in the spirit for which they were intended.

## **GENERAL:**

01. Must be of a model/series that was manufactured 1959 or prior
02. History of tractor is to be provided for announcer
03. Tractor to pull in one class only. Class winner may be allowed to move up to the next class and will pull last for demonstration purposes and will not be able to place.
04. First puller of a class, (except in a pull off) has the option to repull. The decision must be made prior to unhooking from the sled and the puller will repull in 3rd position.
05. During hookup, tractor must be in neutral and driver's hands and feet must be off controls.
06. Hooker/un hooker must stand behind the “apron”
07. Track minimum width is 16 feet Going out of bounds will result in being Red Flagged with distance determined at that point.
08. Puller must be available prior to pull.
09. Absolutely no jerking of sled at start of pull.
10. Puller has 40 feet to restart. Only one restart preferred.
11. Tractors must not exceed a designated maximum speed limit. (currently 4.5 mph but this may change if conditions justify it) The first time the horn blows is a warning and the second time is the end of the pull with distance determined at that point.

## **DRIVER:**

01. No association with drugs or alcohol
02. No passengers on tractor
03. Driver must remain seated during pull
04. Driver must be at least 16 years of age. If under 18 years of age, written authorization of parent/guardian required.
05. Operator must be in attendance at tractor when it is running.
06. Driver must wear closed toed footwear
07. Driver must wear DOT approve helmet (or higher approved and must use the chin strap)

## **TRACTOR:**

1. Tractor must be stock (not modified). This includes having the proper and complete front end assemblies and fenders. (if originally equipped with fenders).
2. Wheel weights are allowed.
3. Suitcase weights are not allowed.
4. Strings etc. attached to governor or carburetor are not allowed.
5. Torque amplifiers may not be shifted while pulling
6. Tires:
  - a) Loaded tires are allowed
  - b) Maximum tire diameter is 38 inches
  - c) Steel wheels are not allowed
  - d) Duals are not allowed
  - e) Cut tires are not allowed
  - f) The use of radial tires is discouraged as they are not consistent with antique tractors.
7. Drawbars:
  - a) All tractors must have a drawbar. If not, the tractor must enter one weight class higher.
  - b) Must be ridged in all directions
  - c) Maximum height is 20 inches
  - d) Maximum height is 20 inches for tractors in the 7600 and 9000 lb class.
  - e) Minimum length is 30 inches measured horizontally from the center of the rear wheel to the point of hook.
  - f) Minimum inside diameter of the drawbar hook is 3 inches.

**CONTINUED >>**

# ANTIQUE TRACTOR SHOW & DEMO PULL CONTINUED

**Tractors will pull in the following weight classes;**

1. 2700 lbs with rims 28" or smaller
2. 3500 lbs with rims 28" or smaller
3. 4000 lbs
4. 4500 lbs
5. 5500 lbs
6. 6500 lbs
7. 7600 lbs
8. 9000 lbs

**NEW:** Effective this 2023 Season, The Executioner Sled Team will **NO LONGER** supply hitches for any class.

It will be up to the puller to have a hitch.

**"NO HITCH NO PULL"**